

Frequently asked questions.

- [Do I need to include a wide-angled lens in my camera setup?](#)
- [How will I know if i have my camera aligned correctly?](#)
- [Will SkyMount fit inside my tennis bag?](#)
- [Is there a complicated assembly process?](#)
- [Am I limited by the type of fencing/court surround to which SkyMount can be attached?](#)
- [Will my video camera be safe and secure?](#)

Do I need to include a wide-angled lens in my camera setup?

We do advise the use of a standard wide-angled lens to ensure the capture of the full width of the tennis court.

How will I know if i have my camera aligned correctly?

Easy. A quick and simple process of trial and error will have you up and running with the correct alignment in no time. Pan and tilt are fully adjustable to allow for variations in fencing height and run-back distance.

Will SkyMount fit inside my tennis bag?

Absolutely. SkyMount is perfectly portable and designed to fit easily inside a tennis bag. SkyMount is contained within a carry-bag (supplied) with the approximate dimensions of L:45cm W:20cm and weight:2kg.

Is there a complicated assembly process?

No not at all. The assembly is extremely quick and simple without need for ladders or any fixtures and fittings.

Am I limited by the type of fencing/court surround to which SkyMount can be attached?

SkyMount utilises a hook-over system to attach to any standard fencing surround (with or without a border pole).

Will my video camera be safe and secure?

FAQs

Yes, as safe as any video device can be when used within the confines of a tennis court with little yellow bullets flying around! SkyMount will attach to any standard video camera at the tripod screw in the conventional manner. SkyMount utilises a hook-over system to attach safely and securely to the back surround of the tennis court.
